

MSG - Rung #2:1 - N10:0

General

This Controller

Communication Command:

Data Table Address:

Size in Elements:

Channel:

Control Bits

Ignore if timed out (TO):

To be retried (NR):

Awaiting Execution (EW):

Continuous Run (CO):

Error (ER):

Message done (DN):

Message Transmitting (ST):

Message Enabled (EN):

Waiting for Queue Space:

Target Device

Message Timeout:

Data Table Address:

Ethernet (IP) Address:

Local / Remote: MultiHop:

Remote Bridge Addr (dec):

Remote Station Address (dec):

Remote Bridge Link ID:


Error

Error Code(Hex): 0

Error Description

No errors


Ensure BOOTP is not enabled in the Channel Configuration of your SLC 5/05



The image shows a 'Channel Configuration' dialog box with a blue title bar and a close button. It has four tabs: 'General', 'Chan. 1 - System', 'Chan. 0 - System', and 'Chan. 0 - User'. The 'General' tab is selected. The 'Driver' is set to 'Ethernet'. The 'Hardware Address' is '00:00:BC:35:35:C7'. The 'IP Address' is '192 . 168 . 1 . 120', 'Subnet Mask' is '255 . 255 . 255 . 0', and 'Gateway Address' is '192 . 168 . 1 . 1'. The 'DHRIO Link ID' is '0'. The 'Pass Thru Routing Table File' is '0'. The 'Default Domain Name' is empty. The 'Primary Name Server' is '0 . 0 . 0 . 0' and the 'Secondary Name Server' is '0 . 0 . 0 . 0'. The 'User Provided Web Pages' section has 'Starting Data File Number' set to '0' and 'Number of Pages' set to '1'. The 'Protocol Control' section has a checkbox for 'Bootp Enable' which is unchecked. The 'Msg Connection Timeout (x 1mS)' is '15000', 'Msg Reply Timeout (x 1mS)' is '3000', and 'Inactivity Timeout (x Min)' is '30'. There are 'Contact' and 'Location' text boxes. At the bottom are 'OK', 'Cancel', 'Apply', and 'Help' buttons.

| | | | |
|------------------------|---------------------|---------------------------------------|-------|
| Driver | Ethernet | | |
| Hardware Address: | 00:00:BC:35:35:C7 | DHRIO Link ID | 0 |
| IP Address: | 192 . 168 . 1 . 120 | Pass Thru Routing Table File | 0 |
| Subnet Mask: | 255 . 255 . 255 . 0 | User Provided Web Pages | |
| Gateway Address: | 192 . 168 . 1 . 1 | Starting Data File Number: | 0 |
| Default Domain Name: | | Number of Pages: | 1 |
| Primary Name Server: | 0 . 0 . 0 . 0 | Protocol Control | |
| Secondary Name Server: | 0 . 0 . 0 . 0 | <input type="checkbox"/> Bootp Enable | |
| | | Msg Connection Timeout (x 1mS): | 15000 |
| | | Msg Reply Timeout (x 1mS): | 3000 |
| | | Inactivity Timeout (x Min): | 30 |
| Contact: | | | |
| Location: | | | |

After a successful read



MSG - N10:0 : (51 Elements)

General

This Controller

Communication Command: Control Bits

Data Table Address: Ignore if timed out (TO):

Size in Elements: To be retried (NR):

Channel: Awaiting Execution (EW):

Continuous Run (CR):

Message done (DN):

Message Transmitting (ST):

Message Enabled (EN):

Waiting for Queue Space:

Error (ER):

Target Device

Message Timeout: Error

Data Table Address: Error Code(Hex):

Ethernet (IP) Address: Error Description

Local / Remote: Local Remote MultiHop: No

Remote Bridge Addr (dec): No errors

Remote Station Address (dec):

Remote Bridge Link ID:

Data File N12 (dec) -- SCRATCH

| Offset | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|--------|-------|-------|----|------|---|---|---|---|---|---|
| N12:0 | 12594 | 13088 | -1 | 4646 | 0 | 0 | 0 | 0 | 0 | 0 |
| N12:10 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| N12:20 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| N12:30 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| N12:40 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| N12:50 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| N12:60 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| N12:70 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| N12:80 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |

SLC5/05

Rev. 1.08